

**PERFORMANCE** 

#### **DESCRIPTION**

### **DIRECTIONS**

### **PROPERTIES**

# HAZAM 1002 WSC Rust Remover

## PRODUCT DATA SHEET

### Non-Harmful Rust Remover

- Rapidly removes rust from ferrous metal and stainless steel
- None Corrosive, non-flammable, non-toxic
- Biodegradable, Contains no VOC's or HAP's
- Contains no solvents, acids, bases or hazardous ingredients
- Works at room temperature, requires no special equipment
- Easy and safe to use
- Safe on soft metals, plastic rubber PVC and other surfaces unharmed by water alone
- Inhibits rust from reforming for up to 4 weeks
- Will not pit or discolor un-rested steel
- Panted pending

Rust remover has been proven effective to remove even deep rust on all types of mild steel and iron. It is safe on al surfaces and will not harm copper, brass, aluminum, plastic rubber or vinyl.

Rust remover is non-toxic, non corrosive, biodegradable and contains no acids or alkalis. It is non -flammable and contains no petroleum solvents.

Pre-clean item to remove oil and dirt. Rinse item and immerse item fully in Rust remover.

Check progress periodically. Once rust is remove, rinse item with water. To prevent re-resulting simply dip the item back into unused rust remover solution and allow to dry. Deeply reused parts (5mm or deeper) may require overnight soaking Rust remover can be used over and over until performance drops off.

- Appearance yellow liquid
- Odor slight odor
- Foam Slight
- pH @ 1% 6.0-7.1
- Environmental Date Biodegradable, Iron Content Dictated Disposal method